

After screwing the guards to the pull rod,loosen the screws marked on the bottom of both sides.



Then mount on a motorcycle (screws 1 and 2)



Finally tighten the loosened screws.

